

Lab 7 Documentation

Name: Crystal Low

Class: EE 104

April 22, 2022

Professor Pham

Abstract: This lab consists of three parts, the first part is to produce the FFT/IFFT Audio Signal Processing with the noise-canceling application. The next part of the lab is to generate a heart rate analysis with time-domain measurements. The last part of this lab is to make some changes to the red alert game development.

Objective: The goal of this lab is to collect three signals with different frequencies and filter out one or more frequencies to convert them back to the time domain as an example of a noise-canceling application using FFT/IFFT audio signal processing. The goal is to create a .wav file to show the noise cancellation. Then create a hospital clinical vital measurement instrument using time-domain measurements by collecting a dataset with a minimum of 30 beats in the preview waveform. The use of WAV to CSV conversion is to be done to complete the plots of the heart rate signal and the time-domain measurements. For the game development part of the goal is to add three hacks and tweaks to the game the options were to change the actor, a need for speed, try again, or shuffle the images.

Instructions:

Import Packages:

FFT/IFFT Audio Signal Processing:

```
import numpy as np
from scipy import fftpack, signal
from matplotlib import pyplot as plt
import pandas as pd
from scipy.io import wavfile
import pandas as pd
import sys, os, os.path
```

Heart Rate Analysis:

```
import heartpy as hp
import matplotlib.pyplot as plt
```

Red Alert:

```
import pgzrun
import pygame
import pgzero
import random
from pgzero.builtins import Actor
from random import randint
```

References:

Module 7 files provided by Professor Pham

https://www.audiocheck.net/audiofrequencysignalgenerator_index.php

<https://www.wavtones.com/functiongenerator.php>

<https://www.kaggle.com/kinguistics/heartbeat-sounds>

FFT/IFFT Audio Signal Processing

In this part of the lab, the goal is to combine three signals that are chosen by the creator and then create a .wav file for an unfiltered signal sound and a filtered signal sound. The FFT graphs are also to be plotted for the filtered and unfiltered signals.



- 1) Declare the constants that will be used to create the equations for the signals

```
16 #Set the constants for the signals to make easier to call
17 timestep = 1/44100
18 noiseamplitude=0.25
19 noiseamplitudetwo=0.5
20
```

- 2) Create three signals of choice with different frequencies and plot them

```
21 #signal 1 @ 215HZ
22 frequency_one=215
23 period_one = 1/frequency_one
24 time_vec = np.arange(0, 1, time_step)
25 signal_one = 1000*(np.sin(2 * np.pi / period_one * time_vec))
26 plt.figure(figsize=(20,10))
27 plt.xticks(fontsize=23)
28 plt.yticks(fontsize=23)
29 plt.xlabel('Time (s)', fontsize=27)
30 plt.ylabel('Amplitude', fontsize=27)
31 plt.title('Signal at 215 Hz', fontsize=40)
32 plt.xlim(0,.01)
33 plt.plot(time_vec, signal_one)
34
35 #signal 2 @ 713Hz
36 frequency_two=713
37 period_two = 1/frequency_two
38 time_vec = np.arange(0, 1, time_step)
39 signal_two = noise_amplitude*1000*(np.sin(2 * np.pi / period_two * time_vec))
40 plt.figure(figsize=(20,10))
41 plt.xticks(fontsize=23)
42 plt.yticks(fontsize=23)
43 plt.xlabel('Time (s)', fontsize=27)
44 plt.ylabel('Amplitude', fontsize=27)
45 plt.title('Signal at 713 Hz', fontsize=40)
46 plt.xlim(0,.01)
47 plt.plot(time_vec, signal_two)
48
49 #signal 3 @ 805
50 frequency_three=805
51 period_three = 1/frequency_three
52 time_vec = np.arange(0, 1, time_step)
53 signal_three = noise_amplitude2*1000*(np.sin(2 * np.pi / period_three * time_vec))
54 plt.figure(figsize=(20,10))
55 plt.xticks(fontsize=23)
56 plt.yticks(fontsize=23)
57 plt.xlabel('Time (s)', fontsize=27)
58 plt.ylabel('Amplitude', fontsize=27)
59 plt.title('Signal at 805 Hz', fontsize=40)
60 plt.xlim(0,.01)
61 plt.plot(time_vec, signal_three)
```

3) Resulting plots of the individual signals chosen




A

- 4) Combine all three frequencies to plot. Line 73 will save the plot for the signals combined in a folder.

```
63 #Combine all signals together into one plot
64 signal_combine = signal_one + signal_two + signal_three
65 plt.figure(figsize=(60,30))
66 plt.xticks(fontsize=60)
67 plt.yticks(fontsize=60)
68 plt.xlabel('Time (s)', fontsize=70)
69 plt.ylabel('Amplitude', fontsize=70)
70 plt.title('Signals Combined with Freqs of 215 Hz, 713 Hz, 805 Hz', fontsize=100)
71 plt.xlim(0,1)
72 plt.plot(time_vec, signal_combine)
73 plt.savefig('Signals_Combined')
```

- 5) The resulting plot of three frequencies combined




- 6) Create a .wav file to play the sound without a filter

```
75 #create .wav file without noise cancelation
76 wavfile.write('unfiltered.wav', 44100, signal_combine.astype(np.int16))
```

7) Create an FFT of the signals combined

```
78 #FFT plot and power for the combined signals
79 signal_fft = fftpack.fft(signal_combine)
80 power = np.abs(signal_fft)**2
81 sample_freq = fftpack.fftfreq(signal_combine.size, d=timestep)
82 plt.figure(figsize=(60, 30))
83 plt.xticks(fontsize=55)
84 plt.yticks(fontsize=55)
85 plt.xlabel('Frequency (Hz)', fontsize=60)
86 plt.ylabel('Power', fontsize=60)
87 plt.title('Combined Signals in Frequency Domain Unfiltered', fontsize=100)
88 plt.xlim(-1000,1000)
89 plt.plot(sample_freq, power)
90
```

8) Results of the FFT plot without the filtering



9) Find the peak of the frequencies and filter high frequencies as the noise cancellation.

```
92     #Finding the peak frequency
93     pos_mask = np.where(sample_freq > 0)
94     freqs = sample_freq[pos_mask]
95     peak_freq = freqs[power[pos_mask].argmax()]
96
97     #Filtering high frequencies
98     high_freq_fft = signal_fft.copy()
99     high_freq_fft[np.abs(sample_freq) > peak_freq] = 0
100    filtered_sig = fftpack.ifft(high_freq_fft)
```

10) Create .wav file with the filtered signals as the noise cancellation

```
102    #create .wav file with noise cancellation
103    wavfile.write('filtered.wav', 44100, filtered_sig.astype(np.int16))
104
```


11) Create a confirmation for filter signal FFT

```
106    #Confirmation for filter signal FFT
107    signal_fft1 = fftpack.fft(filtered_sig)
108    power = np.abs(signal_fft1)**2
109    sample_freq = fftpack.fftfreq(filtered_sig.size, d=timestep)
110
```

12) Plot the FFT filtered signal

```
111    # Filtered FFT (noise cancellation)
112    plt.figure(figsize=(60, 30))
113    plt.xticks(fontsize=60)
114    plt.yticks(fontsize=60)
115    plt.xlabel('Frequency (Hz)', fontsize=60)
116    plt.ylabel('Power', fontsize=60)
117    plt.title('Filtered Signal in Frequency Domain', fontsize=100)
118    plt.xlim(-1500,1500)
119    plt.plot(sample_freq, power)
120
```


13) FFT plot with filtering results




14) Create a time-domain graph with the filtered and the original signal comparison

```
121 #Graph to show the original and filtered time domain signal graph comparison
122 plt.figure(figsize=(60,30))
123 plt.plot(time_vec, signal_combine, label='Original signal')
124 plt.plot(time_vec, filtered_sig, linewidth=5, label='Filtered signal')
125 plt.xticks(fontsize=60)
126 plt.yticks(fontsize=60)
127 plt.xlabel('Time (s)', fontsize=60)
128 plt.ylabel('Amplitude', fontsize=60)
129 plt.title('Time Domain Comparison for the Original and Filtered Signal', fontsize=100)
130 plt.legend(loc='best', fontsize=70)
131 plt.xlim(0,.01)
```

15) Resulting graph for the comparison between the original and filtered signal




16) Filtered and Unfiltered .wav files saved in file explorer



Heart Rate Analysis

Create a python code to plot the heart rate signal and find the time-domain measurements for the heartbeat sound collected.

- 1) First go to this website: <https://www.kaggle.com/kinguistics/heartbeat-sounds> and download a wave file that has a minimum of 30 beats in the waveform.



- 2) After the .wav file was downloaded make sure to convert to .csv file with the .wav to .csv converter provided in Module 7. Run the program and enter in the .wav file downloaded and it will convert to a .csv file.

```

1
2
3 import sys, os, os.path
4 from scipy.io import wavfile
5 import pandas as pd
6
7 input_filename = input("Input file number: ")
8 if input_filename[-3:] != '.wav':
9     print('WARNING!! Input File format should be *.wav')
10    sys.exit()
11
12 samrate, data = wavfile.read(str('./wavfile/' + input_filename))
13 print('Load is Done! \n')
14
15 wavData = pd.DataFrame(data)
16
17 if len(wavData.columns) == 2:
18     print('Stereo .wav file\n')
19     wavData.columns = ['R', 'L']
20     stereo_R = pd.DataFrame(wavData['R'])
21     stereo_L = pd.DataFrame(wavData['L'])
22     print('Saving...\n')
23     stereo_R.to_csv(str(input_filename[:-4] + "_Output_stereo_R.csv"), mode='w')
24     stereo_L.to_csv(str(input_filename[:-4] + "_Output_stereo_L.csv"), mode='w')
25     # wavData.to_csv("Output_stereo_RL.csv", mode='w')
26     print('Save is done ' + str(input_filename[:-4] + '_Output_stereo_R.csv , '
27     + str(input_filename[:-4] + '_Output_stereo_L.csv'))
28
29 elif len(wavData.columns) == 1:
30     print('Mono .wav file\n')
31     wavData.columns = ['M']
32
33     monoData = pd.DataFrame(wavData['M'])
34     print('Saving...\n')
35     monoData.to_csv(str(input_filename[:-4] + "_Output_mono.csv"), mode='w')
36     print('Save is done ' + str(input_filename[:-4] + '_Output_mono.csv'))
37
38

```

Console 14/A x

```

input_filename))
File "C:\Users\Crystal\anaconda3\lib\site-packages\scipy\io\wavfile.py", line 647, in read
    fid = open(filename, 'rb')
FileNotFoundError: [Errno 2] No such file or directory:
'./wavfile/Bunlabelledtest__227_1308594233667_D.wav'

In [6]: runfile('C:/Users/Crystal/Downloads/wav-to-csv-master-20220420T054645Z-001/wav-to-csv-master/wav2csv.py', wdir='C:/Users/Crystal/Downloads/wav-to-csv-master-20220420T054645Z-001/wav-to-csv-master')

Input file number:
Bunlabelledtest__227_1308594233667_D.wav
Load is Done!

Mono .wav file

Save is done
Bunlabelledtest__227_1308594233667_D_Output_mono.csv

```


- 3) Create a python code that will read the .csv file and plot the data that was collected. Set the sample rate accordingly. Line 15 is reading the .csv file and then it will plot the signal created by the .csv file as stated in lines 16 - 18.

```

11 #sampling rate changed accordingly
12 sample_rate = 250
13
14 #read the dataset collected
15 data=hp.get_data('hb.csv')
16 plt.figure(figsize=(12,4))
17 plt.plot(data)
18 plt.show

```

- 4) Results of the signal from the .csv file




5) Line 21 is running the analysis of the sample and then it will plot the results visually.

Line 26-27 will print the computed measurements.

```
19  
20     #runs the analysis  
21     wd, m = hp.process(data, sample_rate)  
22     #visualize in plot of custom size  
23     plt.figure(figsize=(3,4)) #3,4  
24     hp.plotter(wd, m)  
25     #display computed measures  
26     for measure in m.keys():  
27         print('%s: %f' %(measure, m[measure]))
```

6) Results of the Heart Rate Signal Peak Detection and measurements computed



```
Console 1/A x
C:\Users\Crystal\anaconda3\lib\site-packages\heartpy
Low_hearttrateanalysis.py', wdir='C:/Users/Crystal/Desktop/EE104/
EE104_Lab7')
C:\Users\Crystal\anaconda3\lib\site-packages\heartpy
\visualizeutils.py:119: UserWarning: Matplotlib is currently
using module://matplotlib_inline.backend_inline, which is a non-
GUI backend, so cannot show the figure.
fig.show()
bpm: 218.750000
ibi: 274.285714
sdnn: 135.226714
sdsd: 119.296262
rmssd: 196.258424
pnn20: 0.899329
pnn50: 0.758389
hr_mad: 110.000000
sd1: 138.411869
sd2: 117.008035
s: 50879.038040
sd1/sd2: 1.182926
breathingrate: 0.133333
<Figure size 216x288 with 0 Axes>
```

Red Alert

The goal of this lab is to add some minor tweaks to the game red alert. The character was changed to the snowflake image that was provided in the game development file. Then shuffling the images was applied, as well as the action to press the spacebar to continue the game when it was either the game was over or if the player wanted to play the game again. The speed was also changed in the game as

- 1) In Line 17, if the speed is at a lower number faster the characters will move as the level increases. The colors are declared in line 18 for the other colors of the snowflake added.

```
16 #change speed of the game, lower the number the faster it goes
17 START_SPEED = 8
18 COLORS = ["green", "bLue"]
19
```

- 2) To change the character declare the image that was saved in the file. The star was changed to a snowflake image with the + color to dedicated the other colors to the image in line 75.

```

69
70     #change image to a snowflake
71     def create_snowflakes(colors_to_create):
72         #return[]
73         new_snowflakes = []
74         for color in colors_to_create:
75             snowflake = Actor("snowflake-" + color)
76             new_snowflakes.append(snowflake)
77         return new_snowflakes
78

```

- 3) This line is added to create an extra function that will allow the game to restart after a game over or if the player wants to play the game again after completion of the game. Line 49-53 is the function that tell the program when the spacebar is clicked then reply the game.

```

44     def update():
45         global snowflakes, game_complete, game_over, current_level
46         if len(snowflakes) == 0:
47             snowflakes = make_snowflakes(current_level)
48         #add this line to allow spacebar to replay the game
49         if (game_complete or game_over) and keyboard.space:
50             snowflakes = []
51             current_level = 1
52             game_complete = False
53             game_over = False

```

4) Results of the game development with the new changes

